

# Go!Control

HOW TO ARM IN STAY-1 AWAY MODE

# Arming Stay-1 Away Mode

- ▶ If the customer is home and wants to move freely through the home while the system is armed, or arm the system for the night follow these steps...

# Arming Stay-1 Away Mode

1. Arm the system in **Stay Mode**



# Arming Stay-1 Away Mode

2. The Stay Mode allows you to be in the home, but arm and protect the perimeter, such as doors and windows.



# Arming Stay-1 Away Mode

3. Stay Mode does NOT activate your motion sensors.

