

Go!Control

CHANGING A MASTER CODE

Changing The Master Code

- ▶ Perhaps you may want to, or need to, change your Master Code on your Go!Control panel.
- ▶ The Master Code is changed in the User Management section of the menu.

Changing the Master Code

1. Go to **Security, Menu**, and then **Toolbox**.



Changing the Master Code

2. The panel will ask you to enter your current Master Code.
 - If you are setting this up for the first time, the default master code is 1111.



Changing the Master Code

3. Once you're in the *User Toolbox*, select **User Management**.



Changing the Master Code

4. The Master Code is listed as the Master User, or User 1. Select **Master User** and then select **Change Pin**.



Changing the Master Code

5. Type in your desired 4-digit code and your Go!Control panel will ask you to confirm it.

