

# Go!Control

CLEANING THE SCREEN

# Cleaning the Screen

- ▶ There is a special option that allows the display to be cleaned of any fingerprints or dust that might appear on your panel.
- ▶ The option locks the display for 30 seconds so it can be cleaned without sensing any button presses.
- ▶ Clean the display with a soft, dry cloth.
- ▶ To set the display for cleaning, use the following steps...

# Cleaning the Screen

1. Select **Security**, **Menu**, and then **Toolbox**.



# Cleaning the Screen

2. The panel will ask you to enter your current Master Code.



# Cleaning the Screen

3. Once you're in the *User Toolbox*, select **Clean Screen**.



# Cleaning the Screen

4. The cleaning screen will be displayed for 30 seconds. It will show the time remaining. Clean the screen during this time.
  - When the timer expires, the system will return to the toolbox screen.

